

Scroll-Tek Trailer & Box Maintenance

- Oil all drive chains front and rear every week.
- Grease all bearings front and rear every two weeks.
- Check for buildup in and around the front unit or in between layers of belting. Too much buildup causes the limit switch to miscount revolutions.
- Keep tarp closed at all times when loaded or empty. This helps to keep the belt where it belongs.
- Watch for frayed or damaged edges on the belt. Belt traveling to one side will shorten the life of the belt considerably. Adjustments can be made front and rear to center the belt.
- Contact the manufacturer if you need help with maintenance.