



Remote Programming Directions

Step 1: Start truck and engage Hydraulics. This allows you to be able to tell whether or not programming was successful. Ideally programming should take place with an empty trailer.

Step 2: Power on the Computer by turning on the marker lights. The computer receiver is in "learn mode" within the first 15 seconds of powering on. For convenience sake you can use the emergency stop button on the wired hand controller to power off the computer and twist to release to power back on. Green LED light should be illuminated on the computer.

Step 3: Turn ON the New Transmitter to be programmed. Red light on New Transmitter should flash red indicating Power ON.

Step 4: Simultaneously press "Latch DOWN"  & "Latch UP" . HOLD for 1-5 seconds. Transmitter should connect almost instantly.

Repeat steps 2-4 and programming should be finished and remote should function properly.